

Silent Page Tone/Vibrate Paging System



Operating Instructions

INTERPAGE

1-800-992-1000 or 561-844-7900 Ext 4

INTER PAGE TONE ONLY PAGING SYSTEM

IMPORTANT SAFETY INFORMATION

Inter Page products are designed to operate safely when installed and used according to general safety practices. The following requirements should be observed at all times. Do NOT subject this equipment to:

- 1) Mechanical shock
 - 2) Excessive humidity or moisture
 - 3) Extremes of temperature
 - 4) Corrosive liquids
- This equipment is designed for indoor use only, unless expressly stated otherwise, and must not be used in classified Hazardous Areas, including areas containing explosive or flammable vapors, unless express authorization has been given in writing by the manufacturer.
 - Do not obstruct any slots or openings in the product. These are provided for ventilation to ensure reliable operation of the product and to protect it from overheating.
 - Only use a damp cloth for cleaning (not liquid or aerosol based cleaners), and ensure the AC adapter is removed from the unit prior to beginning the cleaning operation.
 - Removal of covers from the equipment must only be undertaken by authorized service personnel.

Warning!

Alteration or modification to any part of this equipment, without the prior written consent of the manufacturer, will invalidate all manufacturer Approvals and Warranties. No adjustments can be undertaken except by a qualified and licensed person as defined by the FCC Rules and Regulations. Operation of altered equipment can result in fines, imprisonment, and/or confiscation of such equipment

Liability

Inter Page does not accept any liability for any damage or injury howsoever resulting from misuse of this equipment. It is the responsibility of the user to ensure that the equipment is operated in the manner for which it was intended and that it is the correct item of equipment for the required task.

Limited Warranty

With respect to the physical documentation and physical electronic circuitry of the Silent Page Tone paging transmitter, the manufacturer warrants same to be free of defects in material and workmanship for a period of one year from the date of purchase. In the event of notification within the warranty period of defects in material or workmanship, the manufacturer and/or Inter Page LP will replace the defective parts and circuitry free of charge. The remedy for breach of this warranty shall be limited to replacement and shall not encompass any other damages, including, but not limited to, loss of profit, special, incidental and consequential damages and similar claims.

Equipment Applications

It is the user's responsibility to determine the suitability of the Silent Page Tone paging system for any given application. Inter Page, or any of its subsidiaries, cannot provide specific advice, as each application will require independent evaluation. The following information, however, may be of benefit:

Equipment Testing

Range tests should be carried out at least once a week, more often when critical criteria apply. They should involve testing the unit past the limit of its required working range so as to ensure a measure of safety. Inter Page suggests that a log should be kept of all the test dates and the information gathered, together with the service records.

The frequency of the tests required will vary between applications. If a pager has been dropped or is worn by a person involved in an accident, the unit should be tested again before re-use. It must be stressed that the physical range tests are essential and any construction work or movement of plant or equipment, could alter the signaling capability of the unit.

Literature

Inter Page operates a policy of continual improvement, and therefore reserve the right to modify or change the specifications without prior notice.

While every possible care has been taken in the preparation of this manual, Inter Page shall not be liable for technical or typographical errors or omissions contained herein, nor for incidental or consequential damage arising from the use of this material.

No part of this document may be photocopied or reproduced in any without the express permission of Inter Page L.P., in writing.

Authorized Distributor:

Inter Page LP
7354 Central Industrial Dr.
Suite 110A .
West Palm Beach, Florida
33404
Telephone: (800) 992-1000
Fax: (561) 844-5844

License

You are cleared to use this equipment within the USA under Inter Page Corporation's license. The License number 9812A030006 issued on 03/31/1999 which expires on 03/31/2014. Certain restrictions apply in respect of output power and antenna installations. If you have any questions contact Inter Page before installation and use. Alternative frequencies are available by formal license application (Form 600) via the FCC. These will not be subject to the same restrictions as the standard assigned license. You should obtain the FCC Rules and Regulations, Title 47, Part 80 to End, including Parts 90 and 95, available from the US Government Printing Office, GPO bookstore or FCC Office.

Package Components:

- 1. SilentPage tone only paging transmitter**
- 2. Power Adapter (8.4 VDC, 1.3 Amp – regulated)**
- 3. Quarter wave whip antenna (with right angled BNC adapter)**
- 4. Operational Manual**

Installation & Operation:



1. Connect the power supply cord to the Silent Page desktop paging system and plug power supply into an AC outlet.
2. Connect antenna to the back of the transmitter.
3. To alert a pager enter the desired pager number on the keyboard of the Silent Page transmitter and press **SEND**.
4. Press **AC** on the keyboard to clear all numbers on the display.
5. Press **C** on the keyboard to clear only the last number on the display.
6. Pressing the **+** button and then the **SEND** button on the keyboard allows you to page the next pager in sequence.
7. Pressing the **-** button and then the **SEND** button on the keyboard allows you to page the previous pager in sequence.

NB: The LED screen on Silent Page transmitter will display the pager number that is being paged when you push SEND.

Each numeric pager when it is paged will display on the pager LED screen the words "TONE ONLY" when the page is received. The pagers are set to "vibrate only" unless otherwise requested.

The Silent Page Paging System can page up to 899 numeric and/or tone/vibrate only pagers and /or coasters.